

System connected to water & power:

Non-Use Period	Action
Up to 30 days	1. Flush process 1 minute. 2. Open the tap for filtered water and let it run for 5 - 15 minutes.
More than 30 days	1. Flush process 1 minute. 2. Open the tap for filtered water and let it run for 30 minutes. If necessary, perform a reset of the child lock.

If you have decided not to disconnect the system from the power and water supply during the period of non-use, no additional filter replacement outside the regular schedule is required. In this case, the Filter Tower has been automatically flushed every 12 hours. Please follow the flushing procedure described above before using the system again.

If you decide to disconnect the AQUANTIS UrQuelle® Diamant system from both the power supply and the water supply during a planned period of non-use (e.g., while on vacation), please make sure to always disconnect both together! Please observe the following instructions before putting the system back into operation:

System disconnected from water & power:

Non-Use Period	Action
Up to 2 weeks	1. Flush process (1 minute). 2. Open the tap for filtered water and let it run for 5 - 15 minutes.
Up to 4 weeks	1. Flush process (1 minute). 2. Open the tap for filtered water and let it run for 30 minutes. If necessary, perform a reset of the child lock. 3. Test the taste of the filtered water (if the taste is not good → replace the filter with Set 2).
	Replace the filter with Set 1. Note: - Before replacing the filter, flush the system, then open the tap for filtered water and let it run as required.

5–8 weeks	- Taste the water after the filter replacement (if the taste is not good → replace the filter with Set 2).
More than 8 weeks	Replace the filter with Set 2 . Note: - Before replacing the filter, flush the system, then open the tap for filtered water and rinse as required.

Notes:

- Filter replacement is simple and explained in the user manual & video.
- Filter Replacement Sets 1+2 are available in our **online store**.
- Gemstone cartridge does not need replacement, only occasional cleaning.